



POLLENSCREEN

INSTALLATION GUIDE

© ALL RIGHTS RESERVED | AIRSCAPE INC.



Installation

- 1) Remove the screen frame from the window. Place on a clean flat surface.
- 2) Lay replacement pollen screen over the frame and cut to size so that it overlaps the frame by at least 2 inches.
- 3) Remove the old screen by gently prying out the spline that holds the screen in the frame channel. Make sure the channel is clean and free of debris. It is good practice to use new spline when re-screening. Replacement spline is readily available at your local hardware store. If needed replacement frame is also available.
- 4) Lay the replacement pollen screen over the frame. Starting in one corner gently press the spline into the frame channel. Pull the spline tight and press into place with a convex spline rolling tool. Gently pull the the screen from the opposite side you are working on. The screen will be pulled tight as the spline presses into the channel. When you reach a corner use a flat head screw driver to press the spline into the channel. Trim the spline to length once you reach your starting point.
 - Be sure to roll the spline in one direction only, not back and forth
 - Roll the spline carefully so that it does not slip and damage the pollen screen
 - Do not over tighten the screen or the frame will warp
- 5) Remove the excess pollen screen using a sharp razor knife. Slowly cut along the outside of spline and the edge of the frame channel.

Cleaning

- 1) Remove the screen from the window.
- 2) Gently rinse the screen with low pressure water. Apply water to the interior side of the screen allowing gravity to flush out any trapped pollen.
- 3) Allow the screen to dry completely before reinstalling.